



EzyHold.com.au

New Application Concrete Top Mount

YOU WILL NEED



**This Protective Equipment
MUST BE WORN**

Tool List:

- Hammer drill
- 6mm masonry bit
- 10mm masonry bit
- Exterior-grade silicone
- Plastic spaghetti (continuous roll-style masonry plug)
- Masking tape
- Spirit level

Please Note

This document is an installation guide only, based on how we install and recommend installing the Ezy Hold unit. The strength and performance of your installation depends on how it is installed. Ezy Hold Pty Ltd accepts no liability for installations that do not follow these guidelines, or for any damage or injury resulting from incorrect installation. If you are unsure about any step, we recommend engaging a licensed tradesperson.

Important — Pool & Wet Area Installations

If your Ezy Hold is being installed near a swimming pool or wet area, it is the responsibility of the installer to check and comply with all local laws and regulations regarding the installation of stainless steel products in that environment. Regulations vary by location — always check the requirements applicable to your area before installation.

INSTALLATION INSTRUCTIONS



This Protective Equipment
MUST BE WORN

Step 1:

Finding the perfect location for your Ezy Hold.

PRO TIP:

Make sure that when your Ezy Hold is installed and your umbrella is being used, it's not too close to any other objects so that your umbrella can open freely.

Step 2:

Sealing the Ezy Hold unit.

Tape up the hole at the bottom of the Ezy Hold unit. Then run a bead of exterior-grade silicone underneath the top plate to the unit itself. This is to ensure that no concrete seeps into the unit during installation. Allow the silicone to partially set before placing the unit into the concrete — it should not be fully wet.

Step 3:

Now that the Ezy Hold has been sealed, place the unit into the wet concrete at the desired location, sitting the Ezy Hold at concrete level. Use a spirit level to confirm the unit is sitting level before the concrete sets.

Step 4:

Allow the concrete to cure fully before drilling — cure times will vary depending on the concrete used and site conditions. Once cured, use a **6mm masonry bit** on the hammer drill and drill 4 holes in the top of the unit. Cut a length of plastic spaghetti (a continuous roll-style masonry plug, available at your local hardware store) to match the depth of each hole and push it in. This ensures the **4 x 65mm screws** provided have the full depth of material to grip into. Screw into the 4 holes firmly.

Using a **10mm masonry bit**, drill a hole through the bottom of the unit and through the concrete below to allow water to drain freely from the unit.

Step 5:

Attaching the mounting pole.

Lift the lid of the Ezy Hold and insert the mounting pole. Hand tighten the shorter star grip to the lid of the Ezy Hold to securely hold the mounting pole in place.

Place the rubber grommet provided around your umbrella pole, then insert your umbrella or an alternative accessory into the mounting pole.

Place the aluminium gussets provided either side of your accessory into the mounting pole. Ensure that the gussets are in line with the star grips and secure firmly. The gussets and rubber have been provided to allow you to centre your accessory inside the mounting pole.

Finally, drill an **8.5mm hole** through the mounting pole and your accessory to maximise strength with the bolt provided.

When you're ready to pack down your umbrella, simply undo the bottom star grip and take out your umbrella, leaving the mounting pole attached to your umbrella. Close the lid and place the decking insert on top of the unit for a seamless and flush finish.

For any further questions or enquiries, please reach out and call us on
0418 555 517 or email us at **info@ezyhold.com.au**

Ezyhold.com.au